

# FLOOR CARE

For commercial and non-welded flooring systems

The below cleaning guidelines are intended for Protect-All® installations without access to a drainage system or non-welded installations.

## You Will Need

- **Spray Bottle**
- **Microfiber Mop**
- **Floor Scrubber**
- **Cleaner** (Approved Cleaners: Simple Green®, Signet® FC3; Ecolab® Oasis™ 115 XP; Ecolab® Kay Chemical QSR 2 in 1 Floor Cleaner or No Rinse Alkaline Floor Cleaner)

### Step 1

Thoroughly sweep area of loose debris.

### Step 2

Place caution sign in a visible area.

### Step 3

Using a microfiber mop and a light cleaning solution mixture, wash the floor. It's important to ring the mop out thoroughly, leaving a minimal amount of liquid on the floor. Where tough stains or scuffs are present, use a floor scrubber.

### Step 4

Using a spray bottle, apply a fresh water rinse to the floor and mop any residual liquid to ensure the cleaner doesn't build up on the floor.

### Interlocking Tiles

Interlocking tiles should only be cleaned using a spray bottle. Dilute a teaspoon of cleaner into a quart-sized spray bottle. Use this method in place of step three. All other steps should be followed when cleaning interlocking tiles.



Flooring That Works For You

For more information give us a call or visit our website today.

**800.544.9538**

**protect-allflooring.com**